

➔ FUSERBLOC - Références

fuser_539_a_1_cat



NFC et DIN - Commande directe de 25 à 125 A

Calibre (A) / Fusible / Taille du boîtier	Nb pôles	Appareil nu	Poignée directe	Contact auxiliaire	Cache-bornes	Contact auxiliaire fusion fusible				
CD 25 A / 10 x 38 / 0	3 P	3631 3002	Noire 3629 4012 ⁽¹⁾⁽²⁾	Type A 1 contact OF 3999 0001 ⁽³⁾ Type A 2 contacts OF 3999 0002 ⁽³⁾	2 / 3 / 4 P intégrés	1 ^{er} contact OF 3994 0303				
	3 P + NC	3631 4002								
	3 P + NP	3631 5002								
CD 32 A / 10 x 38 / 0	3 P	3631 3003								
	3 P + NC	3631 4003								
	3 P + NP	3631 5003								
CD 32 A / 14 x 51 / 0	3 P	3631 3004								
	3 P + NC	3631 4004								
	3 P + NP	3631 5004								
50 A / 14 x 51 / 1	2 P	3615 2005					Noire 3629 7900 ⁽⁵⁾⁽²⁾	Type A 1 contact OF 3999 0021 ⁽³⁾ Type A 2 contacts OF 3999 0022 ⁽³⁾	2 P 3998 2016 ⁽⁴⁾ 3 P 3998 3016 ⁽⁴⁾ 4 P 3998 4016 ⁽⁴⁾	1 ^{er} contact OF 3994 0405 2 ^e contact OF 3994 1901
	3 P	3615 3005								
	4 P	3615 6005								
63 A / 00C / 2	2 P	3615 2006								
	3 P	3615 3006								
	4 P	3615 6006								
100 A / 22 x 58 / 3	2 P	3615 2010								
	3 P	3615 3010								
	4 P	3615 6010								
125 A / 22 x 58 / 3	2 P	3615 2011								
	3 P	3615 3011								
	4 P	3615 6011								
125 A / 00 / 3	2 P	3615 2012								
	3 P	3615 3012								
	4 P	3615 6012								

- (1) Commande frontale directe.
 (2) Standard.
 (3) Maximum 2 contacts.
 (4) Amont ou aval.
 (5) Commande latérale droite directe.